

<b>X-Wheel Lucky Jack (28, 30) Crazy Jack 30 SLS4</b>		
<b>Tubeless tire pressure recommendation (BAR)</b>		
<b>Rider weight (Kg)</b>	<b>Tire size (inch)</b>	
	<b>2,1-2,25</b>	<b>2,4-2,6</b>
45	1	0,9
50		
55	1,2	1,1
60		
65	1,4	1,3
70		
75	1,5	1,4
80		
85	1,7	1,6
90		
95	1,8	1,7
100		
MAX beading pressure: 2,5 BAR		
Pressure is to be considered approximate		
We recommend to inflate the front tire at a pressure 0,1-0,2 BAR lower than the rear one		
The recommended tire pressure with tubes is less than 2 BAR		

<b>X-Wheel Lucky Jack (28, 30) Crazy Jack 30 SLS4</b>		
<b>Pressione massima copertura (BAR)</b>		
<b>Peso Rider (Kg)</b>	<b>Misura copertura (pollici)</b>	
	<b>2,1-2,25</b>	<b>2,4-2,6</b>
45	1	0,9
50		
55	1,2	1,1
60		
65	1,4	1,3
70		
75	1,5	1,4
80		
85	1,7	1,6
90		
95	1,8	1,7
100		
Pressione massima per il tallonamento: 2,5 BAR		
La pressione è da considerarsi approssimativa		
Raccomandiamo di gonfiare la copertura anteriore 0,1-0,2 BAR in meno rispetto alla posteriore		
La pressione consigliata per coperture con camera d'aria è inferiore ai 2 BAR		